

Bluesil™ V 1069

October 2017

Condensation Cure Silicone Elastomer

Description **Bluesil™ V 1069** is a high strength, two component, tin catalyzed, room temperature cure silicone rubber. It is designed as a 30 Shore A, thixotropic (non-sag) rubber providing excellent physical properties and long library life.

Blending of **Bluesil™ V 1069** with **Bluesil™ V 1062** or **Bluesil™ V 1065** provides a unique variety of brush-on coating blends to suit the needs of many applications in the museum, architectural restoration field, theme park and the film industries.

- Applications**
- Museum reproductions
 - On-site architectural reproductions
 - Special effects and props for the film industry
 - Robotic and animatronic skins
 - Theme park props and reproduction mold

Typical Properties

TYPICAL PROPERTIES - AS SUPPLIED		TYPICAL CATALYZED PROPERTIES, Mixed at 24°C (75°F) and 50% R.H.	
<u>Part A - Base Component</u>			
• Color	White	• Mix Ratio , A:B (Parts by weight)	10:1
• Consistency	Thixotropic	• Work Life , minutes	60
• Boeing flow , in. (mm)	0.1-0.15 (2.54-3.81)	• Pot Life , hours ⁽¹⁾	2.75
<u>Part B - Catalyst Component (Hi-Pro Green)</u>			
• Color	Green	• Demold Time , hrs at RT	16
• Viscosity , cP. (mPa.s)	90		

TYPICAL PROPERTIES OF CURED RUBBER, Cured 7 days at 24°C (75°F) and 50% RH		
Property	Test Method	Value Hi-Pro Green
• Specific Gravity		1.11
• Hardness (Shore A) ⁽²⁾	ASTM D2240	30
• Tensile Strength , psi (N/mm ²)	ASTM D412	580 (4)
• Elongation (%)	ASTM D412	420
• Tear Resistance , ppi (N/mm)	ASTM D624, Die B	80 (14)
• Linear Shrinkage (%) ⁽³⁾ 24 hours		<0.1
7 days		0.25
• Coverage - cu. in/lb. (cc/kg)		24.9 (901)
• Temperature Range °C (°F)		-50 to 150 (-58 to 302)

(1) Time at which material gels. (2) 0.5 in. (1.27 cm) thick cup specimen. (3) 8x8x0.25 in (20.3x20.3x0.64 cm) molded sheet, cured at room temperature

Please note: The typical properties listed in this bulletin are not intended for use in preparing specifications for any particular application of BLUESIL™ silicone materials. Please contact our Technical Service Department for assistance in writing specifications.

Instructions for use

1. Stir the base (Part A) well before use (except when machine dispensing).
2. Shake the catalyst container (Part B) well before use.
3. Weigh the desired amount of base into a clean mixing container. Tip the container and roll the base all the way around the side wall up to two inches from the top. This will prevent the catalyst from becoming absorbed into the container. It is recommended that the container be filled to not more than 1/3 the container depth to allow sufficient room for expansion during the deaeration procedure.

4. Weigh the proper amount of catalyst into the container. Mix the base and catalyst together by stirring with a stiff, flat ended metal spatula until a uniform color is obtained. Scrape the container walls and bottom well to insure a thorough mix.
5. Place the container into a vacuum chamber and evacuate the entrapped air from the mixture using a vacuum pump capable of achieving 29 inches of mercury vacuum. The mixture will rise, crest and then collapse in the container. Interruption (bumping) of the vacuum may be necessary to prevent overflowing the container. Keep the mixture under full vacuum for 2-3 minutes after the material has receded in the container.
6. Bleed air slowly into the vacuum chamber. When the chamber is at atmospheric equilibrium, remove the cover plate and take out the container.
7. Pour the deaired material slowly in a steady stream from one end of the mold box so that the material flows evenly over the pattern. This should minimize entrapment of air bubbles under the flowing material. A "print" coat may be poured first over the pattern which will also help reduce the possibility of entrapping air on the pattern and in the cured rubber. A mold release (petroleum jelly) may be applied on the pattern first to improve release.
8. Allow the rubber to cure for 16-24 hours at 75±5°F (24°C) before removing the cured rubber mold from the pattern. Heat acceleration is not recommended with this product.
9. For best results, allow the mold to air cure an additional 24 hours before using it in production. Full cure is achieved in 3-7 days.
10. For bonding to wood or metals, use **Bluesil™ V 04** primer. Follow recommendations on the **Bluesil™ V 04** technical data sheet for best results.

PROCESSING INFORMATION

CATALYZED PROCESSING PROPERTIES ARE AFFECTED BY TEMPERATURE AND HUMIDITY VARIATION

1. For best results, mix and cure the material at 75°F (24°C) and 50% relative humidity.
 2. Higher temperature and humidity will decrease the work life and pot life of the material. The faster cure will also affect the flow properties. Refrigeration of the base prior to use in hot environments has shown to improve the handling properties of this material.
 3. Lower temperatures and humidity will increase the work life and pot life of the material. The slower cure will increase the flow time. Cure temperatures below 68°F (20°C) are not recommended and have been found to cause a reduction in final cure hardness and properties.
 4. It is important that the catalyst containers are tightly closed after use. Catalyst exposed to air for extended periods of time will hydrolyze (cure). An indication of hydrolysis is a film or crust formation on the surface of the catalyst. The use of hydrolyzed catalyst is not recommended and may cause incomplete cure.
-

Bluesil™ V 1069

Storage and shelf life	When stored in its original unopened packaging, at a temperature of 24°C (75°F), Bluesil™ V 1069 may be stored for 18 months from the date of manufacture. Beyond this date, Elkem Silicones no longer guarantees that the product meets the sales specifications.
Safety	Please consult the Safety Data Sheet of Bluesil™ V 1069 .
Packaging	Bluesil™ V 1069 is available in 20 kg and 200 kg containers.

Bluesil™ is a registered Trademark of **Elkem SILICONES**

 EUROPE	 NORTH AMERICA	 LATIN AMERICA	 ASIA PACIFIC
<p><i>Elkem Silicones France</i> 21 Avenue Georges Pompidou F69486 Lyon Cedex 03 FRANCE Tel. (33) 4 72 13 19 00 Fax (33) 4 72 13 19 88</p>	<p><i>Elkem Silicones USA</i> Two Tower Center Boulevard Suite 1601 East Brunswick, NJ 08816-1100 United States Tel. (1) 732 227 2060 Fax (1) 732 249 7000</p>	<p><i>Elkem Silicones Brazil Ltda.</i> Av. Maria Coelho Aguiar, 215 Bloco G - 1º Andar 05804-902 - São Paulo - SP - Brazil Tel. (55) 11 3747 7887 Fax (55) 11 3741 7718</p>	<p><i>Elkem Silicones Hong Kong</i> Trading Co. Ltd. Unit C, 18/F Manulife Tower 169 Electric Road North Point-Hong Kong Tel. (852) 3106 8200 Fax (852) 2979 0241</p>
<p>Warning to the users The information contained in this document is given in good faith based on our current knowledge. It is only an indication and is in no way binding, particularly as regards infringement of or prejudice to third party rights through the use of our products. Elkem SILICONES guarantees that its products comply with its sales specifications. This information must on no account be used as a substitute for necessary prior tests which alone can ensure that a product is suitable for given use. Users are responsible for ensuring compliance with local legislation and for obtaining the necessary certifications and authorizations. Users are requested to check that they are in possession of the latest version of this document and Elkem SILICONES is at their disposal to supply any additional information.</p>			